



SECTION A  
SCALE: 1/8" = 1'-0"




PART PLAN @ WELDING LAB  
SCALE: 1/4" = 1'-0"

DUCT ENCLOSURE FOR WELDING LAB VENTILATION CHANGE ORDER




PART PLAN @ WELDING LAB  
SCALE: 1/8" = 1'-0"




SECTION A  
SCALE: 1/2" = 1'-0"

SUPPORT FOR HEAT RECOVERY UNIT @ WELDING LAB




TYPICAL HANGER SUPPORT @ H. + V. EQUIP.




TENDON ROD INSTALLATION LAYOUT  
NOT TO SCALE

NOTES:

- 1) TURNBUCKLE LOCATIONS NOT TO INTERFERE W/ DRAIN
- 2) KEEP ROD LOCATIONS AS CLOSE TO TOP OF FOOTING AS POSSIBLE
- 3) INSTALL 1/2\"/>



TYPICAL SECTION @ COLUMN-PIER  
SCALE: 1/2" = 1'-0"



SECTION A  
SCALE: 1 1/2" = 1'-0"